

February 08, 2022

**Vista Work Order No. 2201160**

Mr. Steve Dyke  
Holland Board of Public Works  
42 S. River Ave  
Holland, MI 49423

Dear Mr. Dyke,

Enclosed are the results for the sample set received at Vista Analytical Laboratory on January 18, 2022 under your Project Name 'Holland Biosolids PFAS'.

Vista Analytical Laboratory is committed to serving you effectively. If you require additional information, please contact me at 916-673-1520 or by email at [jfox@vista-analytical.com](mailto:jfox@vista-analytical.com).

Thank you for choosing Vista as part of your analytical support team.

Sincerely,

Jamie Fox  
Laboratory Director



*Vista Analytical Laboratory certifies that the report herein meets all the requirements set forth by NELAP for those applicable test methods. Results relate only to the samples as received by the laboratory. This report should not be reproduced except in full without the written approval of Vista.*

## Vista Work Order No. 2201160

### Case Narrative

#### Sample Condition on Receipt:

One sludge sample was received and stored securely in accordance with Vista standard operating procedures and EPA methodology. The sample was received in good condition and within the recommended temperature requirements.

#### Analytical Notes:

##### PFAS Isotope Dilution Method

The sample was extracted and analyzed for a selected list of PFAS using Vista's Isotope Dilution Method. The results for PFHxS, PFOA, PFOS, MeFOSAA and EtFOSAA include both linear and branched isomers. Results for all other analytes include the linear isomers only.

##### Holding Times

The sample was extracted and analyzed within the hold times.

##### Quality Control

The Initial Calibration and Continuing Calibration Verifications met the method acceptance criteria.

A Method Blank and Ongoing Precision and Recovery (OPR) sample were extracted and analyzed with the preparation batch. No analytes were detected in the Method Blank above the Reporting Limit (RL). The OPR recoveries were within the method acceptance criteria.

The labeled standard recoveries outside the acceptance criteria are listed in the table below.

#### QC Anomalies

| LabNumber  | SampleName     | Analysis                     | Analyte      | Flag | %Rec |
|------------|----------------|------------------------------|--------------|------|------|
| 2201160-01 | Biosolids PFAS | PFAS Isotope Dilution Method | 13C3-PFBA    | H    | 20.4 |
| 2201160-01 | Biosolids PFAS | PFAS Isotope Dilution Method | 13C2-PFDA    | H    | 21.4 |
| 2201160-01 | Biosolids PFAS | PFAS Isotope Dilution Method | 13C2-8:2 FTS | H    | 24.2 |
| 2201160-01 | Biosolids PFAS | PFAS Isotope Dilution Method | d3-MeFOSAA   | H    | 13.3 |
| 2201160-01 | Biosolids PFAS | PFAS Isotope Dilution Method | 13C2-PFUnA   | H    | 15.6 |
| 2201160-01 | Biosolids PFAS | PFAS Isotope Dilution Method | d5-EtFOSAA   | H    | 14.1 |
| 2201160-01 | Biosolids PFAS | PFAS Isotope Dilution Method | 13C2-PFDoA   | H    | 10.8 |
| 2201160-01 | Biosolids PFAS | PFAS Isotope Dilution Method | 13C2-PFTeDA  | H    | 13.1 |

H = Recovery was outside laboratory acceptance criteria.

## TABLE OF CONTENTS

|                         |    |
|-------------------------|----|
| Case Narrative.....     | 1  |
| Table of Contents.....  | 3  |
| Sample Inventory.....   | 4  |
| Analytical Results..... | 5  |
| Qualifiers.....         | 12 |
| Certifications.....     | 13 |
| Sample Receipt.....     | 16 |

# Sample Inventory Report



| Vista<br>Sample ID | Client<br>Sample ID | Sampled         | Received        | Components/Containers |
|--------------------|---------------------|-----------------|-----------------|-----------------------|
| 2201160-01         | Biosolids PFAS      | 17-Jan-22 10:00 | 18-Jan-22 09:44 | HDPE Jar, 6 oz        |

## **ANALYTICAL RESULTS**

**Sample ID: Method Blank**
**PFAS Isotope Dilution Method**

| Client Data |                               |         |       | Laboratory Data |              |         |         |
|-------------|-------------------------------|---------|-------|-----------------|--------------|---------|---------|
| Name:       | Holland Board of Public Works | Matrix: | Solid | Lab Sample:     | B22A111-BLK1 | Column: | BEH C18 |
| Project:    | Holland Biosolids PFAS        |         |       |                 |              |         |         |

| Analyte      | CAS Number  | Conc. (ng/g ) | RL   | Qualifiers | Batch   | Extracted | Samp Size | Analyzed        | Dilution |
|--------------|-------------|---------------|------|------------|---------|-----------|-----------|-----------------|----------|
| PFBA         | 375-22-4    | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFPeA        | 2706-90-3   | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFBS         | 375-73-5    | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 4:2 FTS      | 757124-72-4 | ND            | 2.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFHxA        | 307-24-4    | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFPeS        | 2706-91-4   | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| HFPO-DA      | 13252-13-6  | ND            | 2.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFHpA        | 375-85-9    | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| ADONA        | 919005-14-4 | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFHxS        | 355-46-4    | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 6:2 FTS      | 27619-97-2  | ND            | 2.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFOA         | 335-67-1    | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFHpS        | 375-92-8    | ND            | 2.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFNA         | 375-95-1    | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFOSA        | 754-91-6    | ND            | 2.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFOS         | 1763-23-1   | ND            | 2.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 9Cl-PF3ONS   | 756426-58-1 | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFDA         | 335-76-2    | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 8:2 FTS      | 39108-34-4  | ND            | 2.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFNS         | 68259-12-1  | ND            | 2.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| MeFOSAA      | 2355-31-9   | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| EtFOSAA      | 2991-50-6   | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFUnA        | 2058-94-8   | ND            | 2.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFDS         | 335-77-3    | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 11Cl-PF3OUdS | 763051-92-9 | ND            | 2.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFDoA        | 307-55-1    | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFTTrDA      | 72629-94-8  | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| PFTeDA       | 376-06-7    | ND            | 1.00 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |

| Labeled Standards | Type | % Recovery | Limits   | Qualifiers | Batch   | Extracted | Samp Size | Analyzed        | Dilution |
|-------------------|------|------------|----------|------------|---------|-----------|-----------|-----------------|----------|
| 13C3-PFBA         | IS   | 86.8       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C3-PFPeA        | IS   | 91.1       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C3-PFBS         | IS   | 93.3       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C3-HFPO-DA      | IS   | 88.3       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C2-4:2 FTS      | IS   | 99.8       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C2-PFHxA        | IS   | 87.7       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C4-PFHpA        | IS   | 87.8       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C3-PFHxS        | IS   | 99.0       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C2-6:2 FTS      | IS   | 88.2       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |

|                                |                                     |
|--------------------------------|-------------------------------------|
| <b>Sample ID: Method Blank</b> | <b>PFAS Isotope Dilution Method</b> |
|--------------------------------|-------------------------------------|

|  |  |
|--|--|
| <b>Client Data</b><br>Name: Holland Board of Public Works<br>Project: Holland Biosolids PFAS | <b>Laboratory Data</b><br>Matrix: Solid<br>Lab Sample: B22A111-BLK1<br>Column: BEH C18 |
|--|--|

| Labeled Standards | Type | % Recovery | Limits   | Qualifiers | Batch   | Extracted | Samp Size | Analyzed        | Dilution |
|-------------------|------|------------|----------|------------|---------|-----------|-----------|-----------------|----------|
| 13C5-PFNA         | IS   | 77.8       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C8-PFOA         | IS   | 22.2       | 10 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C2-PFOA         | IS   | 84.4       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C8-PFOS         | IS   | 90.2       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C2-PFDA         | IS   | 65.4       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C2-8:2 FTS      | IS   | 73.2       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| d3-MeFOSAA        | IS   | 52.7       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C2-PFUnA        | IS   | 50.9       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| d5-EtFOSAA        | IS   | 52.5       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C2-PFDoA        | IS   | 52.5       | 25 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |
| 13C2-PFTeDA       | IS   | 64.4       | 20 - 150 |            | B22A111 | 31-Jan-22 | 0.500 g   | 04-Feb-22 14:58 | 1        |

RL - Reporting limit

The results are reported in dry weight.  
 The sample size is reported in wet weight.  
 Results reported to RL.

When reported, PFHxS, PFOA, PFOS, MeFOSAA and EtFOSAA include both linear and branched isomers. Only the linear isomer is reported for all other analytes.

**Sample ID: OPR**
**PFAS Isotope Dilution Method**

| Client Data       |                               |                  |           |       |          | Laboratory Data |             |           |           |                 |          |
|-------------------|-------------------------------|------------------|-----------|-------|----------|-----------------|-------------|-----------|-----------|-----------------|----------|
| Name:             | Holland Board of Public Works |                  | Matrix:   | Solid |          | Lab Sample:     | B22A111-BS1 |           | Column:   | BEH C18         |          |
| Project:          | Holland Biosolids PFAS        |                  |           |       |          |                 |             |           |           |                 |          |
| Analyte           | CAS Number                    | Amt Found (ng/g) | Spike Amt | % Rec | Limits   | Qualifiers      | Batch       | Extracted | Samp Size | Analyzed        | Dilution |
| PFBA              | 375-22-4                      | 19.1             | 20.0      | 95.7  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFPeA             | 2706-90-3                     | 19.6             | 20.0      | 98.2  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFBS              | 375-73-5                      | 20.8             | 20.0      | 104   | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 4:2 FTS           | 757124-72-4                   | 19.4             | 20.0      | 96.9  | 60 - 145 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFHxA             | 307-24-4                      | 19.8             | 20.0      | 99.1  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFPeS             | 2706-91-4                     | 20.1             | 20.0      | 101   | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| HFPO-DA           | 13252-13-6                    | 22.5             | 20.0      | 112   | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFHpA             | 375-85-9                      | 18.6             | 20.0      | 92.9  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| ADONA             | 919005-14-4                   | 18.6             | 20.0      | 93.2  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFHxS             | 355-46-4                      | 19.6             | 20.0      | 97.8  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 6:2 FTS           | 27619-97-2                    | 19.4             | 20.0      | 97.2  | 60 - 140 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFOA              | 335-67-1                      | 18.4             | 20.0      | 91.9  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFHpS             | 375-92-8                      | 20.8             | 20.0      | 104   | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFNA              | 375-95-1                      | 20.6             | 20.0      | 103   | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFOSA             | 754-91-6                      | 17.8             | 20.0      | 89.1  | 65 - 140 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFOS              | 1763-23-1                     | 21.2             | 20.0      | 106   | 65 - 140 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 9CI-PF3ONS        | 756426-58-1                   | 18.5             | 20.0      | 92.7  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFDA              | 335-76-2                      | 19.4             | 20.0      | 97.0  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 8:2 FTS           | 39108-34-4                    | 20.3             | 20.0      | 101   | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFNS              | 68259-12-1                    | 18.3             | 20.0      | 91.5  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| MeFOSAA           | 2355-31-9                     | 19.1             | 20.0      | 95.7  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| EtFOSAA           | 2991-50-6                     | 18.7             | 20.0      | 93.7  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFOuA             | 2058-94-8                     | 20.3             | 20.0      | 102   | 65 - 140 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFDS              | 335-77-3                      | 16.7             | 20.0      | 83.5  | 50 - 150 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 11CI-PF3OUdS      | 763051-92-9                   | 24.9             | 20.0      | 125   | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFDaA             | 307-55-1                      | 20.6             | 20.0      | 103   | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFTTrDA           | 72629-94-8                    | 21.6             | 20.0      | 108   | 60 - 140 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| PFTTeDA           | 376-06-7                      | 19.5             | 20.0      | 97.4  | 65 - 135 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| Labeled Standards | Type                          |                  |           | % Rec | Limits   | Qualifiers      | Batch       | Extracted | Samp Size | Analyzed        | Dilution |
| 13C3-PFBA         | IS                            |                  |           | 87.6  | 25 - 150 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C3-PFPeA        | IS                            |                  |           | 91.6  | 25 - 150 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C3-PFBS         | IS                            |                  |           | 88.1  | 25 - 150 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C3-HFPO-DA      | IS                            |                  |           | 88.4  | 25 - 150 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C2-4:2 FTS      | IS                            |                  |           | 89.5  | 25 - 150 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C2-PFHxA        | IS                            |                  |           | 87.6  | 25 - 150 |                 | B22A111     | 31-Jan-22 | 0.500 g   | 04-Feb-22 15:08 | 1        |



**Sample ID: OPR**
**PFAS Isotope Dilution Method**

| Client Data       |                               |         |          |            | Laboratory Data |             |           |                 |          |
|-------------------|-------------------------------|---------|----------|------------|-----------------|-------------|-----------|-----------------|----------|
| Name:             | Holland Board of Public Works | Matrix: | Solid    |            | Lab Sample:     | B22A111-BS1 | Column:   | BEH C18         |          |
| Project:          | Holland Biosolids PFAS        |         |          |            |                 |             |           |                 |          |
| Labeled Standards | Type                          | % Rec   | Limits   | Qualifiers | Batch           | Extracted   | Samp Size | Analyzed        | Dilution |
| 13C4-PFHpA        | IS                            | 88.7    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C3-PFHxS        | IS                            | 92.9    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C2-6:2 FTS      | IS                            | 83.1    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C5-PFNA         | IS                            | 80.0    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C8-PFOA         | IS                            | 19.8    | 10 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C2-PFOA         | IS                            | 86.4    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C8-PFOS         | IS                            | 90.3    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C2-PFDA         | IS                            | 68.9    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C2-8:2 FTS      | IS                            | 76.4    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| d3-MeFOSAA        | IS                            | 56.3    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C2-PFUnA        | IS                            | 56.5    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| d5-EtFOSAA        | IS                            | 54.4    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C2-PFDoA        | IS                            | 56.2    | 25 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |
| 13C2-PFTeDA       | IS                            | 65.5    | 20 - 150 |            | B22A111         | 31-Jan-22   | 0.500 g   | 04-Feb-22 15:08 | 1        |

**Sample ID: Biosolids PFAS**
**PFAS Isotope Dilution Method**

| Client Data       |                               |                 |                 | Laboratory Data |                 |           |           |                 |          |
|-------------------|-------------------------------|-----------------|-----------------|-----------------|-----------------|-----------|-----------|-----------------|----------|
| Name:             | Holland Board of Public Works | Matrix:         | Sludge          | Lab Sample:     | 2201160-01      | Column:   | BEH C18   |                 |          |
| Project:          | Holland Biosolids PFAS        | Date Collected: | 17-Jan-22 10:00 | Date Received:  | 18-Jan-22 09:44 |           |           |                 |          |
| Location:         | Holland Biosolids PFAS        |                 |                 | % Solids:       | 4.07            |           |           |                 |          |
| Analyte           | CAS Number                    | Conc. (ng/g )   | RL              | Qualifiers      | Batch           | Extracted | Samp Size | Analyzed        | Dilution |
| PFBA              | 375-22-4                      | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFPeA             | 2706-90-3                     | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFBS              | 375-73-5                      | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 4:2 FTS           | 757124-72-4                   | ND              | 2.01            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFHxA             | 307-24-4                      | 3.15            | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFPeS             | 2706-91-4                     | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| HFPO-DA           | 13252-13-6                    | ND              | 2.01            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFHpA             | 375-85-9                      | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| ADONA             | 919005-14-4                   | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFHxS             | 355-46-4                      | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 6:2 FTS           | 27619-97-2                    | ND              | 2.01            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFOA              | 335-67-1                      | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFHpS             | 375-92-8                      | ND              | 2.01            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFNA              | 375-95-1                      | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFOSA             | 754-91-6                      | ND              | 2.01            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFOS              | 1763-23-1                     | ND              | 2.01            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 9Cl-PF3ONS        | 756426-58-1                   | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFDA              | 335-76-2                      | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 8:2 FTS           | 39108-34-4                    | ND              | 2.01            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFNS              | 68259-12-1                    | ND              | 2.01            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| MeFOSAA           | 2355-31-9                     | 1.88            | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| EtFOSAA           | 2991-50-6                     | 1.62            | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFUnA             | 2058-94-8                     | ND              | 2.01            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFDS              | 335-77-3                      | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 11Cl-PF3OUdS      | 763051-92-9                   | ND              | 2.01            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFDoA             | 307-55-1                      | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFTrDA            | 72629-94-8                    | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| PFTeDA            | 376-06-7                      | ND              | 1.00            |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| Labeled Standards | Type                          | % Recovery      | Limits          | Qualifiers      | Batch           | Extracted | Samp Size | Analyzed        | Dilution |
| 13C3-PFBA         | IS                            | 20.4            | 25 - 150        | H               | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C3-PFPeA        | IS                            | 29.7            | 25 - 150        |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C3-PFBS         | IS                            | 34.8            | 25 - 150        |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C3-HFPO-DA      | IS                            | 30.8            | 25 - 150        |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C2-4:2 FTS      | IS                            | 33.3            | 25 - 150        |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C2-PFHxA        | IS                            | 31.9            | 25 - 150        |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C4-PFHpA        | IS                            | 35.4            | 25 - 150        |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C3-PFHxS        | IS                            | 34.3            | 25 - 150        |                 | B22A111         | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |

|                                  |                                     |
|----------------------------------|-------------------------------------|
| <b>Sample ID: Biosolids PFAS</b> | <b>PFAS Isotope Dilution Method</b> |
|----------------------------------|-------------------------------------|

|  |  |
|--|--|
| <b>Client Data</b><br>Name: Holland Board of Public Works<br>Project: Holland Biosolids PFAS<br>Location: Holland Biosolids PFAS | <b>Laboratory Data</b><br>Matrix: Sludge<br>Date Collected: 17-Jan-22 10:00<br>Lab Sample: 2201160-01<br>Date Received: 18-Jan-22 09:44<br>Column: BEH C18<br>% Solids: 4.07 |
|--|--|

| Labeled Standards | Type | % Recovery | Limits   | Qualifiers | Batch   | Extracted | Samp Size | Analyzed        | Dilution |
|-------------------|------|------------|----------|------------|---------|-----------|-----------|-----------------|----------|
| 13C2-6:2 FTS      | IS   | 40.0       | 25 - 150 |            | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C5-PFNA         | IS   | 25.4       | 25 - 150 |            | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C8-PFOSA        | IS   | 13.1       | 10 - 150 |            | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C2-PFOA         | IS   | 31.0       | 25 - 150 |            | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C8-PFOS         | IS   | 25.5       | 25 - 150 |            | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C2-PFDA         | IS   | 21.4       | 25 - 150 | H          | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C2-8:2 FTS      | IS   | 24.2       | 25 - 150 | H          | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| d3-MeFOSAA        | IS   | 13.3       | 25 - 150 | H          | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C2-PFUnA        | IS   | 15.6       | 25 - 150 | H          | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| d5-EtFOSAA        | IS   | 14.1       | 25 - 150 | H          | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C2-PFDoA        | IS   | 10.8       | 25 - 150 | H          | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |
| 13C2-PFTeDA       | IS   | 13.1       | 20 - 150 | H          | B22A111 | 31-Jan-22 | 12.2 g    | 04-Feb-22 15:18 | 1        |

RL - Reporting limit

The results are reported in dry weight.  
 The sample size is reported in wet weight.  
 Results reported to RL.

When reported, PFHxS, PFOA, PFOS, MeFOSAA and EtFOSAA include both linear and branched isomers. Only the linear isomer is reported for all other analytes.

## DATA QUALIFIERS & ABBREVIATIONS

|         |  |
|---------|--|
| B       | This compound was also detected in the method blank  |
| Conc.   | Concentration  |
| CRS     | Cleanup Recovery Standard  |
| D       | Dilution   |
| DL      | Detection Limit  |
| E       | The associated compound concentration exceeded the calibration range of the instrument                 |
| H       | Recovery and/or RPD was outside laboratory acceptance limits   |
| I       | Chemical Interference  |
| IS      | Internal Standard  |
| J       | The amount detected is below the Reporting Limit/LOQ   |
| LOD     | Limit of Detection   |
| LOQ     | Limit of Quantitation  |
| M       | Estimated Maximum Possible Concentration (CA Region 2 projects only)                                   |
| MDL     | Method Detection Limit   |
| NA      | Not applicable   |
| ND      | Not Detected   |
| OPR     | Ongoing Precision and Recovery sample  |
| P       | The reported concentration may include contribution from chlorinated diphenyl ether(s).                |
| Q       | The ion transition ratio is outside of the acceptance criteria.  |
| RL      | Reporting Limit  |
| RL      | For 537.1, the reported RLs are the MRLs.  |
| TEQ     | Toxic Equivalency, sum of the toxic equivalency factors (TEF) multiplied by the sample concentrations. |
| TEQMax  | TEQ calculation that uses the detection limit as the concentration for non-detects                     |
| TEQMin  | TEQ calculation that uses zero as the concentration for non-detects                                    |
| TEQRisk | TEQ calculation that uses ½ the detection limit as the concentration for non-detects                   |
| U       | Not Detected (specific projects only)  |
| *       | See Cover Letter   |

Unless otherwise noted, solid sample results are reported in dry weight. Tissue samples are reported in wet weight.

### Vista Analytical Laboratory Certifications

| Accrediting Authority                                | Certificate Number |
|--|--------------------|
| Alaska Department of Environmental Conservation      | 17-013             |
| Arkansas Department of Environmental Quality         | 21-023-0           |
| California Department of Health – ELAP               | 2892               |
| DoD ELAP - A2LA Accredited - ISO/IEC 17025:2005      | 3091.01            |
| Florida Department of Health                         | E87777-26          |
| Hawaii Department of Health                          | N/A                |
| Louisiana Department of Environmental Quality        | 01977              |
| Maine Department of Health                           | 2020018            |
| Massachusetts Department of Environmental Protection | M-CA413            |
| Michigan Department of Environmental Quality         | 9932               |
| Minnesota Department of Health                       | 1980678            |
| New Hampshire Environmental Accreditation Program    | 207720             |
| New Jersey Department of Environmental Protection    | CA003              |
| New York Department of Health                        | 11411              |
| Ohio Environmental Protection Agency                 | 87778              |
| Oregon Laboratory Accreditation Program              | 4042-016           |
| Pennsylvania Department of Environmental Protection  | 017                |
| Texas Commission on Environmental Quality            | T104704189-21-12   |
| Vermont Department of Health                         | VT-4042            |
| Virginia Department of General Services              | 10769              |
| Washington Department of Ecology                     | C584               |
| Wisconsin Department of Natural Resources            | 998036160          |

*Current certificates and lists of licensed parameters are located in the Quality Assurance office and are available upon request.*

## NELAP Accredited Test Methods

| MATRIX: Air   |           |
|---|-----------|
| Description of Test   | Method    |
| Determination of Polychlorinated p- Dioxins & Polychlorinated Dibenzofurans | EPA 23    |
| Polychlorinated Dibenzodioxins in Ambient Air by GC/HRMS                    | EPA TO-9A |

| MATRIX: Biological Tissue   |                |
|---|----------------|
| Description of Test   | Method         |
| Tetra- through Octa-Chlorinated Dioxins and Furans by Isotope Dilution GC/HRMS              | EPA 1613B      |
| Brominated Diphenyl Ethers by HRGC/HRMS   | EPA 1614A      |
| Chlorinated Biphenyl Congeners in Water, Soil, Sediment, and Tissue by GC/HRMS              | EPA 1668A/C    |
| Pesticides in Water, Soil, Sediment, Biosolids, and Tissue by HRGC/HRMS                     | EPA 1699       |
| Perfluorinated Alkyl Acids in Drinking Water by SPE and LC/MS/MS                            | EPA 537        |
| Polychlorinated Dibenzo-p-Dioxins and Polychlorinated Dibenzofurans by GC/HRMS              | EPA 8280A/B    |
| Polychlorinated Dibenzodioxins (PCDDs) and Polychlorinated Dibenzofurans (PCDFs) by GC/HRMS | EPA 8290/8290A |

| MATRIX: Drinking Water  |                |
|---|----------------|
| Description of Test   | Method         |
| Tetra- through Octa-Chlorinated Dioxins and Furans by Isotope Dilution GC/HRMS  | EPA 1613/1613B |
| Perfluorinated Alkyl Acids in Drinking Water by SPE and LC/MS/MS  | EPA 537        |
| Perfluorinated Alkyl Acids in Drinking Water by SPE and LC/MS/MS  | EPA 537.1      |
| Determination of Per- and Polyfluoroalkyl Substances in Drinking Water by Isotope Dilution Anion Exchange Solid Phase Extraction and Liquid Chromatography/Tandem Mass Spectrometry | EPA 533        |
| Perfluorooctanesulfonate (PFOS) and Perfluorooctanoate (PFOA) - Method for Unfiltered Samples Using Solid Phase Extraction and Liquid Chromatography/Mass Spectrometry              | ISO 25101 2009 |

| MATRIX: Non-Potable Water   |                |
|---|----------------|
| Description of Test   | Method         |
| Tetra- through Octa-Chlorinated Dioxins and Furans by Isotope Dilution GC/HRMS              | EPA 1613B      |
| Brominated Diphenyl Ethers by HRGC/HRMS   | EPA 1614A      |
| Chlorinated Biphenyl Congeners in Water, Soil, Sediment, and Tissue by GC/HRMS              | EPA 1668A/C    |
| Pesticides in Water, Soil, Sediment, Biosolids, and Tissue by HRGC/HRMS                     | EPA 1699       |
| Perfluorinated Alkyl Acids in Drinking Water by SPE and LC/MS/MS                            | EPA 537        |
| Dioxin by GC/HRMS   | EPA 613        |
| Polychlorinated Dibenzo-p-Dioxins and Polychlorinated Dibenzofurans by GC/HRMS              | EPA 8280A/B    |
| Polychlorinated Dibenzodioxins (PCDDs) and Polychlorinated Dibenzofurans (PCDFs) by GC/HRMS | EPA 8290/8290A |

| MATRIX: Solids  |                |
|---|----------------|
| Description of Test   | Method         |
| Tetra-Octa Chlorinated Dioxins and Furans by Isotope Dilution GC/HRMS                       | EPA 1613       |
| Tetra- through Octa-Chlorinated Dioxins and Furans by Isotope Dilution GC/HRMS              | EPA 1613B      |
| Brominated Diphenyl Ethers by HRGC/HRMS   | EPA 1614A      |
| Chlorinated Biphenyl Congeners in Water, Soil, Sediment, and Tissue by GC/HRMS              | EPA 1668A/C    |
| Pesticides in Water, Soil, Sediment, Biosolids, and Tissue by HRGC/HRMS                     | EPA 1699       |
| Perfluorinated Alkyl Acids in Drinking Water by SPE and LC/MS/MS                            | EPA 537        |
| Polychlorinated Dibenzo-p-Dioxins and Polychlorinated Dibenzofurans by GC/HRMS              | EPA 8280A/B    |
| Polychlorinated Dibenzodioxins (PCDDs) and Polychlorinated Dibenzofurans (PCDFs) by GC/HRMS | EPA 8290/8290A |







## PERFLUOROALKYL AND POLYFLUOROALKYL SUBSTANCES (PFAS) MINIMUM LABORATORY ANALYTE LIST

Below is the minimum laboratory PFAS analyte list for analysis of deer, drinking water, groundwater, surface water, soil, wastewater effluent, and landfill leachate samples collected by Michigan's Departments of Environment, Great Lakes, and Energy, Health and Human Services, Agriculture and Rural Development, and Natural Resources.


This minimum analyte list was developed based on the potential for these chemicals to be found in Michigan, the availability of the chemical standards used for testing, and the ability of available laboratories to test for these PFAS. This list includes PFAS that can be tested for in drinking water using United States Environmental Protection Agency (USEPA) Methods 537 Rev.1.1 or 537.1, which are the only methods that should be used when analyzing drinking water samples. Other testing methodology may be used to test for PFAS in other media (not drinking water). This list is not exhaustive of PFAS in Michigan's environment.

A fish icon (🐟) precedes those compounds that are also currently being tested for in fish tissue.

| Analyte Name                   | Acronym | Fluorinated Carbon Chain Length | Molecular Formula                                 | CAS Number | USEPA Method 537 Rev. 1.1 | USEPA Method 537.1 |
|--------------------------------|---------|---------------------------------|---|------------|---------------------------|--------------------|
| 🐟 Perfluorotetradecanoic acid  | PFTeA   | C <sub>14</sub>                 | C <sub>13</sub> F <sub>27</sub> COOH              | 376-06-7   | X                         |                    |
| 🐟 Perfluorotridecanoic acid    | PFTriA  | C <sub>13</sub>                 | C <sub>12</sub> F <sub>25</sub> COOH              | 72629-94-8 | X                         |                    |
| 🐟 Perfluorododecanoic acid     | PFDaA   | C <sub>12</sub>                 | C <sub>11</sub> F <sub>23</sub> COOH              | 307-55-1   | X                         |                    |
| 🐟 Perfluoroundecanoic acid     | PFUnA   | C <sub>11</sub>                 | C <sub>10</sub> F <sub>21</sub> COOH              | 2058-94-8  | X                         |                    |
| 🐟 Perfluorodecanoic acid       | PFDA    | C <sub>10</sub>                 | C <sub>9</sub> F <sub>19</sub> COOH               | 335-76-2   | X                         |                    |
| 🐟 Perfluorononanoic acid       | PFNA    | C <sub>9</sub>                  | C <sub>8</sub> F <sub>17</sub> COOH               | 375-95-1   | X                         |                    |
| 🐟 Perfluorooctanoic acid       | PFOA    | C <sub>8</sub>                  | C <sub>7</sub> F <sub>15</sub> COOH               | 335-67-1   | X                         |                    |
| 🐟 Perfluoroheptanoic acid      | PFHpA   | C <sub>7</sub>                  | C <sub>6</sub> F <sub>13</sub> COOH               | 375-85-9   | X                         |                    |
| 🐟 Perfluorohexanoic acid       | PFHxA   | C <sub>6</sub>                  | C <sub>5</sub> F <sub>11</sub> COOH               | 307-24-4   | X                         |                    |
| 🐟 Perfluoropentanoic acid      | PFPeA   | C <sub>5</sub>                  | C <sub>4</sub> F <sub>9</sub> COOH                | 2706-90-3  |                           |                    |
| 🐟 Perfluorobutanoic acid       | PFBA    | C <sub>4</sub>                  | C <sub>3</sub> F <sub>7</sub> COOH                | 375-22-4   |                           |                    |
| 🐟 Perfluorodecanesulfonic acid | PFDS    | C <sub>10</sub>                 | C <sub>10</sub> F <sub>21</sub> SO <sub>3</sub> H | 335-77-3   |                           |                    |
| Perfluorononanesulfonic acid   | PFNS    | C <sub>9</sub>                  | C <sub>9</sub> F <sub>19</sub> SO <sub>3</sub> H  | 68259-12-1 |                           |                    |
| 🐟 Perfluorooctanesulfonic acid | PFOS    | C <sub>8</sub>                  | C <sub>8</sub> F <sub>17</sub> SO <sub>3</sub> H  | 1763-23-1  | X                         |                    |
| Perfluoroheptanesulfonic acid  | PFHpS   | C <sub>7</sub>                  | C <sub>7</sub> F <sub>15</sub> SO <sub>3</sub> H  | 375-92-8   |                           |                    |
| 🐟 Perfluorohexanesulfonic acid | PFHxS   | C <sub>6</sub>                  | C <sub>6</sub> F <sub>13</sub> SO <sub>3</sub> H  | 355-46-4   | X                         |                    |
| Perfluoropentanesulfonic acid  | PFPeS   | C <sub>5</sub>                  | C <sub>5</sub> F <sub>11</sub> SO <sub>3</sub> H  | 2706-91-4  |                           |                    |
| 🐟 Perfluorobutanesulfonic acid | PFBS    | C <sub>4</sub>                  | C <sub>4</sub> F <sub>9</sub> SO <sub>3</sub> H   | 375-73-5   | X                         |                    |

**Perfluoroalkyl and Polyfluoroalkyl Substances (PFAS)  
Minimum Laboratory Analyte List**

2201160 5.8.C

| Analyte Name  | Acronym          | Fluorinated<br>Carbon<br>Chain<br>Length | Molecular Formula  | CAS Number  | USEPA<br>Method<br>537<br>Rev. 1.1 | USEPA<br>Method<br>537.1 |
|---|------------------|--|--|-------------|------------------------------------|--------------------------|
|  Perfluorooctanesulfonamide | PFOSA            | C <sub>8</sub>                           | C <sub>8</sub> F <sub>17</sub> SO <sub>2</sub> NH <sub>2</sub>                                       | 754-91-6    |                                    |                          |
| Fluorotelomer sulfonic acid 8:2   | FtS 8:2          | C <sub>8</sub>                           | C <sub>8</sub> F <sub>17</sub> CH <sub>2</sub> CH <sub>2</sub> SO <sub>3</sub>                       | 39108-34-4  |                                    |                          |
| Fluorotelomer sulfonic acid 6:2   | FtS 6:2          | C <sub>6</sub>                           | C <sub>6</sub> F <sub>13</sub> CH <sub>2</sub> CH <sub>2</sub> SO <sub>3</sub>                       | 27619-97-2  |                                    |                          |
| Fluorotelomer sulfonic acid 4:2   | FtS 4:2          | C <sub>4</sub>                           | C <sub>4</sub> F <sub>9</sub> CH <sub>2</sub> CH <sub>2</sub> SO <sub>3</sub>                        | 757124-72-4 |                                    |                          |
| 2-(N-Ethylperfluorooctanesulfonamido)<br>acetic acid  | N-EtFOSAA        | C <sub>8</sub>                           | C <sub>8</sub> F <sub>17</sub> SO <sub>2</sub> N(C <sub>2</sub> H <sub>5</sub> )CH <sub>2</sub> COOH | 2991-50-6   | X                                  |                          |
| 2-(N-Methylperfluorooctanesulfonamido)<br>acetic acid   | N-MeFOSAA        | C <sub>8</sub>                           | C <sub>8</sub> F <sub>17</sub> SO <sub>2</sub> N(CH <sub>3</sub> )CH <sub>2</sub> COOH               | 2355-31-9   | X                                  |                          |
| Hexafluoropropylene oxide dimer acid  | HFPO-DA          | C <sub>6</sub>                           | C <sub>6</sub> HF <sub>11</sub> O <sub>3</sub>   | 13252-13-6  |                                    | X                        |
| 11-chloroeicosafluoro-3-oxaundecane-<br>1-sulfonic acid   | 11Cl-<br>PF30UdS | C <sub>10</sub>                          | C <sub>10</sub> HF <sub>20</sub> ClSO <sub>4</sub>   | 763051-92-9 |                                    | X                        |
| 9-chlorohexadecafluoro-3-oxanone-1-<br>sulfonic acid  | 9Cl-PF30NS       | C <sub>8</sub>                           | C <sub>8</sub> HF <sub>16</sub> ClSO <sub>4</sub>  | 756426-58-1 |                                    | X                        |
| 4,8-dioxa-3H-perfluorononanoic acid   | ADONA            | C <sub>7</sub>                           | C <sub>7</sub> H <sub>2</sub> F <sub>12</sub> O <sub>4</sub>   | 919005-14-4 |                                    | X                        |

## Laboratories Providing PFAS Analytical Services

(The list that turns up in the search results from the following links does not constitute an endorsement of those firms on the list, nor is it a statement against any firm not on the list. Additionally, the capacity of the labs to provide services consistent with EGLE's recommendations above has not been verified and these details should be addressed prior to contracting with the laboratories below.)

The **United States Environmental Protection Agency (US EPA)** has a list of laboratories approved under the UCMR3 program using US EPA Method 537 Rev. 1.1 for PFAS in drinking water:

<https://www.epa.gov/dwucmr/third-unregulated-contaminant-monitoring-rule>

The **United States Department of Defense, Environmental Laboratory Accreditation Program (US DoD ELAP)** maintains a list of labs for the determination of PFAS in various environmental media other than drinking water on the Defense Environmental Network Information Exchange (DENIX) server:

<http://www.denix.osd.mil/edqw/accreditation/accreditedlabs/>

## Contact Information

Questions regarding PFAS in general, contact:

- **MDHHS General Information**  
(517) 373-3740
- **EGLE Environmental Assistance Center**  
(800) 662-9278

Questions regarding laboratory information, contact:

- **MDHHS Chemistry & Toxicology Division**  
(517) 335-9490
- **EGLE Drinking Water Analysis Laboratory**  
(517) 335-8184



# Sample Log-In Checklist

 Page # 1 of 1

 Vista Work Order #: 2201160

 TAT STD

|                     |  |              |                                 |     |                        |                             |       |
|---------------------|--|--------------|---------------------------------|-----|------------------------|-----------------------------|-------|
| Samples Arrival:    | Date/Time<br><u>01/18/22</u> <u>0944</u> |              | Initials:<br><u>(Signature)</u> |     | Location: <u>WR-2</u>  |                             |       |
|                     |  |              |                                 |     | Shelf/Rack: <u>N/A</u> |                             |       |
| Delivered By:       | FedEx                                    | <u>(UPS)</u> | On Trac                         | GLS | DHL                    | Hand Delivered              | Other |
| Preservation:       | Ice                                      |              | <u>(Blue Ice)</u>               |     | Techni Ice             | Dry Ice                     | None  |
| Temp °C: <u>5.8</u> | (uncorrected)                            |              | Probe used: <u>(Y)</u> / N      |     |                        | Thermometer ID: <u>DT-5</u> |       |
| Temp °C: <u>5.8</u> | (corrected)                              |              |                                 |     |                        |                             |       |

|   | YES                                      | NO                                  | NA                                  |
|---|--|-------------------------------------|-------------------------------------|
| Shipping Container(s) Intact?                     | <input checked="" type="checkbox"/>      |                                     |                                     |
| Shipping Custody Seals Intact?                    |  | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Airbill <u>—</u>                                  | Trk # <u>1Z4XX1332210010823</u>          | <input checked="" type="checkbox"/> |                                     |
| Shipping Documentation Present?                   |  |                                     |                                     |
| Shipping Container                                | Vista                                    | <u>(Client)</u>                     | Retain                              |
|   |  | <u>(Return)</u>                     | Dispose                             |
| Chain of Custody / Sample Documentation Present?  | <input checked="" type="checkbox"/>      |                                     |                                     |
| Chain of Custody / Sample Documentation Complete? | <input checked="" type="checkbox"/>      |                                     |                                     |
| Holding Time Acceptable?                          | <input checked="" type="checkbox"/>      |                                     |                                     |
| Logged In:  | Date/Time<br><u>01/18/22</u> <u>1422</u> | Initials:<br><u>(Signature)</u>     | Location: <u>WR-2</u>               |
|   |  |                                     | Shelf/Rack: <u>A-3</u>              |
| COC Anomaly/Sample Acceptance Form completed?     |  |                                     |                                     |

Comments:

# CoC/Label Reconciliation Report WO# 2201160

| LabNumber  | CoC Sample ID    | SampleAlias            | Sample Date/Time | Container      | BaseMatrix | Sample Comments |
|------------|------------------|------------------------|------------------|----------------|------------|-----------------|
| 2201160-01 | A Biosolids PFAS | Holland Biosolids PFAS | 17-Jan-22 10:00  | HDPE Jar, 6 oz | Solid      |                 |

Checkmarks indicate that information on the COC reconciled with the sample label.  
Any discrepancies are noted in the following columns.

|   | Yes                                 | No                       | NA                       | Comments: |
|---|-------------------------------------|--------------------------|--------------------------|-----------|
| Sample Container Intact?                    | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |           |
| Sample Custody Seals Intact?                | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |           |
| Adequate Sample Volume?                     | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |           |
| Container Type Appropriate for Analysis(es) | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |           |

Preservation Documented: Na2S2O3 Trizma NH4CH3CO2

None

Other

All

Verified by/Date:

 01/18/22